

## Software Update Procedure

### Important notes:

- The software update will load the new settings to your Guia system. Therefore before updating software, please save the current settings by using Settings → Save Settings. Enter a name for the settings for use after update.
- The USB key that you use for updating Guia software must be formatted with FAT32 so that it can hold long filenames.
- Download the software update file to the hard drive of your computer. **Do not copy it to the USB key used for update.**
- When you are ready, you can do the following:

### 1) Make Update Disk:

- a) Unzip the Guia Update Zip file that you download from email or internet. An example of update zip file is *guiaengnorth172.zip*.
- b) Copy the 3 files **p151updg.tgz**, **p151upds.tgz** and **update** to the USB key. This is called the update key. Note that the **update** file does not have file extension.
- c) Eject and unplug the USB key from your computer.

### 2) Update Software in Guía:

- a) Once the update files are on the USB key, turn the Guía on.
- b) Select "**Help**" from the System menu: Press key <0>, <IIII> to highlight "**Help**", then <Enter> to select it.
- c) Select "**Update**" from the Help menu by using key <IIII> and press <Enter>.
- d) Plug the USB update key to Guía USB port, **wait for 10 seconds** then press <Enter>.
- e) If everything is OK, the message "**update successful**" will be displayed on screen.
- f) Press <Enter> to close the message. When screen is blank, remove the USB key. The Guia will reboot.
- g) After rebooting, run "**Application**".
- h) Check the version of the program: Select "**Help**" → "**About**". It should show the version of software you installed to the Guia.

- i) Select Settings → Load Settings. Select the Setting filename you made before updating software.
- j) Exit all the way to Main menu. Run “**Application**” again.
- k) Check all settings to confirm all parameters properly set. When done, the Guia is ready for flight.
- l) If you got the message "**update failed**" at step e), unplug the USB stick from Guía and repeat this procedure again. Make sure you get all the update files described in (1b).

For further help or information, please contact AG-NAV staff at:

Toll free : 1-800-99 AGNAV or 1-800-992-4628  
Or : 1-705-734-0909  
Fax : 1-705-735-0880  
Email : [general@agnav.com](mailto:general@agnav.com)

Mail : AG-NAV Inc.  
30 Churchill Drive  
Barrie, Ontario, L4N 8Z5  
Canada