

Software Update Procedure

Important notes:

- The software update will load the new settings to your LiNav system. Therefore before updating software, please record the current settings for use after update.
- The USB key that you use as an update disk for the LiNav system must be formatted with FAT32 so that it can hold long filenames.
- If you download the update from AGNAV website, download the software update to the hard drive of your computer first. Do not copy it to the USB key used for update.
- When you are ready, you can do the following:

1) Make Update Disk:

- a) Make sure the USB key is empty.
- b) Make sure you have the right update file for your LiNav system. Copy the **p151upd_g.tgz** file to the USB key. If you use the update files on LiNav CD, copy both files: **update** (no extension) and **p151upd_g.tgz** to the USB key.
- c) Unplug USB key from your computer after copying the files. Plug it to your computer again and check if the above filenames remain on the USB key. Note that all filenames must be in lower case.

2) Update Software in LiNav System:

- a) Once the update files are on the USB stick, turn the LiNav on.
- b) Select "**Help**" from the System menu: Press key <0>, <IIII> to highlight "**Help**", then <Enter> to select it.
- c) Select "**Update**" from the Help menu by using key <IIII> and press <Enter>.
- d) Plug the USB stick to LiNav USB port, **wait for 10 seconds** then press <Enter>.
- e) If everything is OK, the message "**update successful**" will be displayed on screen.
- f) Press <Enter> to close the message then remove the USB key. System will reboot after a few seconds. If not, turn off LiNav and on again.
- g) After rebooting, run "**Navigate**".
- h) Check the version of the program: Select "**Help**" → "**About**".

- i) If you got the message "**update failed**" at step e), unplug the USB stick from LiNav and repeat the procedure from step 1d. Make sure you get all the update files described in 1b.

Normally the software update will load the new settings and overwrite the current settings in your LiNav system. Before flying with the new software, please check all settings in Navigate → Settings.

For further help or information, please contact AG-NAV staff at:

Toll free : 1-800-99 AGNAV or 1-800-992-4628
Or : 1-905-967-0909
Fax : 1-905-967-0808
Email : general@agnav.com

Mail : AG-NAV Inc.
1228 Gorham Street, Suite 21
Newmarket, Ontario, L3Y 8Z1
Canada