

Software Update Procedure

Important notes:

- The software update will load the new settings to your LiNav system. Therefore before updating software, please record the current settings for use after update. You can use the function Navigate → Settings → Save Settings to save your current settings to a file.
- The USB key that you use as an update disk for the LiNav system must be formatted with FAT32 so that it can hold long filenames.
- If you download the update from AGNAV website, download the software update to the hard drive of your computer first. Do not copy it to the USB key used for update.
- When you are ready, you can do the following:

1) Make Update Disk:

- a) Make sure the USB key is empty.
- b) Make sure you have the right update file for your LiNav system. Copy the **p151upd_g.tgz** file to the USB key. If you use the update files on LiNav CD, copy both files: **update** (no extension) and **p151upd_g.tgz** to the USB key. Note that all filenames must be in lower case.
- c) Eject the USB key and unplug it from your computer.

2) Update Software in LiNav System:

- a) Once the update files are on the USB stick, turn the LiNav on.
- b) Select "**Help**" from the System menu: Press key <0>, <IIII> to highlight "**Help**", then <Enter> to select it.
- c) Select "**Update**" from the Help menu by using key <IIII> and press <Enter>.
- d) Plug the USB stick to LiNav USB port, **wait for 10 seconds** then press <Enter>.
- e) If everything is OK, the message "**update successful**" will be displayed on screen.
- f) Press <Enter> to close the message. When screen is blank, unplug the USB key. System will reboot after a few seconds.
- g) After rebooting, run "**Navigate**".

- h) Check the version of the program: Select "**Help**" → "**About**".
- i) If you got the message "**update failed**" at step e), unplug the USB stick from LiNav and repeat the procedure from step 1d. Make sure you get all the update files described in 1b.

Normally the software update will load the new settings and overwrite the current settings in your LiNav system. Before flying with the new software, please check all settings in Navigate → Settings.

If you saved your settings before updating software, you can load your settings back by selecting Navigate → Settings → Load Settings. Then exit all the way to the Main Menu and run "Navigate" again. Check all settings to make sure you have correct settings before flight.

For further help or information, please contact AG-NAV staff at:

Toll free : 1-800-99 AGNAV or 1-800-992-4628
Or : 1-705-734-0909
Fax : 1-705-735-0880
Email : general@agnav.com

Mail : AG-NAV Inc.
30 Churchill Drive
Barrie, Ontario, L4N 8Z5
Canada